



Pre-Operative TPLO Radiograph Guide



1. The lateral TPLO radiograph is taken with the stifle AND hock in 90 degrees of flexion. (aka 90/90)
2. On the lateral radiograph try to get the femoral condyles super-imposed and the fabellae overlapping such that they look as one.



3. On the AP radiograph bisect the fabellae.
4. Include the hock joint so that we can make measurements (try to center calcaneus)
5. Center the patella.

6. Ideally a radiographic length marker (eg 2.5cm or 10cm) should be on radiographs to correct for magnification.
7. Left/right radiographic marker should be in every radiograph.

Post-operative TPLO radiographs

